

How to Import Start Lists for the Scoreboard from Hy-Tek software


There are two steps to transferring Start Lists from the computer running your Hy-Tek software to the computer controlling your scoreboard display.

1. Save the Start Lists to a USB flash drive or 3.5-inch floppy disk.
 - a. Insert the removable media into your Hy-Tek computer.
 - b. From the File menu in Hy-Tek, choose Export, then *Start Lists for Scoreboard*, then *Start Lists for CTS*. Select the appropriate destination for the removable media you have chosen. If you have questions, consult your Hy-Tek documentation.
 - c. Remove the media from your Hy-Tek computer.

2. Transfer the data from the USB flash drive or 3.5-inch floppy disk to the DisplayLink computer.
 - a. Insert the removable media into your DisplayLink computer.
 - b. Open the file transfer utility by double clicking the icon on the DisplayLink computer's desktop.
 - c. Select the drive you are copying from in the *Select Source Drive* menu.
 - d. Select the folder on the removable media from the *Select Source Folder* menu.
 - e. In the *Transfer the Files* section, click Copy *.scb files.
 - f. When finished, click Quit.
 - g. Remove the media from your DisplayLink computer.

NOTE: If the icon for the utility is no longer on your computer's desktop, it can be found in C:\DisplayLink3\DLUSBtransfer.

Information is subject to change. Please see the CTS customer support website for latest details: www.coloradotime.com/customersupport



Colorado Time Systems
1551 E. 11th Street, Loveland, CO 80537
Phone: 970-667-1000 x256 Toll free: 800-287-0653 ext. 256
Fax: 970-667-1032 E-mail: customerservice@coloradotime.com
www.coloradotime.com Shop online: <http://secure.coloradotime.com>