








## Slide Mount Connection Hub

The slide mount bracket for the under-block connection hub makes it easy to remove the connection hub for storage and re-install it quickly and easily for meets or practice.

### Contents

	Quantity	Part #	Description
	4	011-133	8-32 x $\frac{3}{4}$ Phillips machine screw
	4	011-325	8-32 kepnut
	4	011-354	#8 x $\frac{3}{4}$ Phillips wood screw
	1	080-613	Slide mount bracket
	4	011-355	#10-24 x $\frac{3}{4}$ coarse thread Phillips machine screw
	4	011-356	#10 coarse thread nylon locknut
	1	080-524	Mounting bracket

## **Tools Required**

Phillips screwdriver  
Drill with 1/8" bit  
Pencil

## **Assembly Instructions**

1. Using the slide mount bracket as a template, mark hole locations on underside of block.
2. Drill holes. Screw slide mount bracket to block using supplied wood screws (011-354).
3. Attach connection hub DP-4.5QC to mounting bracket (080-524) using the smaller machine screws ((8-32 x 3/4 -- 011-133) and the kepnuts (011-325).
4. Attach the speaker to the bottom of the mounting bracket using the larger machine screws (10-24 x 3/4 -- 011-355) and the locknuts (011-356).
5. During use, slide the top of the mounting bracket into the sleeve created by the slide mount bracket. When finished, slide it out and store in a safe, dry location.

Colorado Time Systems  
1551 E. 11<sup>th</sup> Street, Loveland, CO 80537  
Phone: 970-667-1000 x256 Fax: 970-667-1032 Toll free: 800-287-0653 ext. 256  
www.coloradotime.com E-mail: customerservice@coloradotime.com